## STARTAG X-LARGE LASER SHEETS 32TV LABEL SIZE: 40 X 30MM

The following details will facilitate accurate configuration of the above laser labels with **Microsoft WORD 2007** for windows.

- 1. Open Word
- 2. Click on 'Tools, 'Envelopes and Labels'
- 3. Select 'Labels' then 'Options'
- 4. Under printer information select Laser
- Tray select Manual feed (hand feeding is recommended)
- Click on Details or New Label to customize your label Top margin: 1.75 cm Side margin: 1.8 cm Vertical pitch: 3.3 cm Horizontal pitch: 4.5 cm Label height: 3 cm Label width: 4 cm Number across: 4 Number down: 8

The above settings can be used for previous versions of Word, however, the terminology may vary.

- 7. Set page size to A4 (21 x 29.7cm)
- 8. Select a name for the label; X-Large Lab Tags

## Please Note

We recommend that prior to printing the labels, a print test is carried out on a plain A4 sheet, then held against label sheet to ensure that all print is included within the label area. Rigorous testing has shown that a slight variation may occur with different makes and models of Laser Printers.

STORAGE – PRIOR TO ATTACHMENT SHEETS (PRINTED & UNPRINTED) SHOULD BE STORED IN THE GRIP-SEAL POLYBAG AND CARDBOARD WALLET PROVIDED AT BETWEEN 10°C/25°C AND 35%/65% RH

THESE LABELS ARE NOT DESIGNED FOR USE WITH INKJET PRINTERS

BATCH NO: XXXXXX