

# Mix it well, for **best results.**

## DILUTION CHART FOR 5 LITRE CONTAINERS WITH PUMP

DILUTION	SIZE OF CONTAINER TO BE FILLED					
	500ml	750ml	1 Litre	5 Litre	10 Litre	20 Litre
<b>1:10 / 10% Discard jars</b>	2 pumps or 50ml	3 pumps or 75ml	4 pumps or 100ml	20 pumps or 500ml	-	-
<b>1:20 / 5% Soaking</b>	1 pumps or 25ml	Self-dose or 37.5ml	2 pumps or 50ml	10 pumps or 250 ml	20 pumps or 500ml	-
<b>1:50 / 2% Body Spills</b>	Self-dose or 10ml	Self-dose or 15ml	Self-dose or 20ml	4 pumps or 100ml	8 pumps or 200ml	16 pumps or 400ml
<b>1:100 or 1% General Use</b>	Self-dose or 5ml	Self-dose or 7.5ml	Self-dose or 10ml	2 pumps or 50ml	4 pumps or 100ml	8 pumps or 200ml

### Chemgene Disinfectant

Clear, Unfrgranced  
**XTM309**

Blue, Eucalyptus  
**XTM308**



### Distel® Disinfectant

Clear, Unfrgranced  
**TM309**

Blue, Eucalyptus  
**TM308**

